



2005-2010 Jeep Grand Cherokee (WK) Rear Shocks

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

Rear Parts List:

2 – Rear 2.5 Remote Reservoir Shocks (25001-166)

Tools Required:

15mm Socket/Wrench
Floor Jack/Jack Stands

*2005-2010 Jeep Grand Cherokee
DEM PERFORMANCE SERIES*



REAR: With the vehicle on level ground, block the front tires to prevent the vehicle from rolling. Using a floor jack, Raise the rear end and support the frame rails on jack stands. Remove rear tires. **NOTE: Never work under an unsupported vehicle.**

1. Remove the rear shocks using a 15mm socket/wrench to remove the 2 mounting bolts (nuts are welded).



IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701 Most important after the install, Feel the difference and have fun.



2005-2010 Jeep Grand Cherokee (WK) Rear Shocks

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

2. Install King Shocks. Shocks are side specific, make sure the shocks are mounted so the reservoir is facing forward with the hose facing out towards the tire. Use the factory bolts to install new shocks and torque to factory specs.



Make sure everything is installed correctly and all hardware is tight before reinstalling tires. Install tires, remove jack stands and lower vehicle to the ground. Recheck all hardware and lug nuts after 100 miles and periodically after that as part of routine maintenance.



King Shocks
12472 Edison Way
Garden Grove, CA 92841
www.kingshocks.com

IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701 Most important after the install, Feel the difference and have fun.